Unity Connection Voice Mail

with Unified Messaging

To Call	Voicemail from y Press the Me Enter your PI Mailbox ID: 5-dig Starter PIN: 1 2 3	 Voicemail from an outside line: Dial (978) 619-5665 Enter your Mailbox ID Number followed by # Enter your PIN followed by # 									
	Press 1	During I	Review		After M	After Message Review					
	To play new	Repeat Save		Delete		Repeat Sa		ve Delete			
	messages:	1	2	3		1	2		3		
	<u>or</u>	Slow 4	Vol.	Fast		Reply	Fwd.	-	New		
	Press 3	4 Back	5 Pause	6 F. Fwd.		4 Back	5)	6 Prop.		
	To review	7	8	9		7	8	3	9		
	old (saved)	Cancel	Help	End		Cancel	He	•	New		
	messages:	*	0	#		*	0)	#		
Main Menu	Press 2 To send a message:	 spell the name of the person or distribution list followed by # Press # to confirm Press 9 1 to add a 2 Request 3 Mark mean 4 Set future 5 Review rest 6 Re-record 						ssage urgent return receipt ssage private e delivery ecording d message e message			
	Press 4	For setup options:Press 1 – Edit the standard greeting Press 2 – Turn on/off alternate greeting Press 3 – Edit other greetings							Tips:		
									Exit <u>or</u>		
									back up		
	Press 4 – Play all greetings										
		Press 2 – Message Settings:							0 Help		
	Press 1 – Message notification								##		
		Press 3 – Menu style							Number		
	Press 4 – Private lists Press 3 – Preferences:							c	and spelling		
									entry		
		Press 1 – PIN Press 2 – Recorded name Press 3 – Directory listing							toggle		
					3						



While on-hook, pressing the up option displays your Recent call list and pressing the down option displays your programmed Speed Dials.

- 6 Hold Places a call on hold and retrieves a held call.
- 7 Conference Initiates a conference call.
- 8 Transfer Initiates a call transfer.
- 9 Speakerphone Activates (solid green) and deactivates the speakerphone.
- 10 Headset Activates (solid green) and deactivates the user-provided headset.
- 11 Mute Deactivates (solid red) and reactivates the microphone.
- **12** Keypad Allows you to dial phone numbers, enter letter and select menu items that are numerically numbered.
- **13 Volume** Adjusts the phone's ringer volume while on-hook and the handset, speakerphone and headset volumes while off-hook.
- 14 Contacts Personal and Corporate Directory look-up access.
- 15 Applications Recents (view by All calls <u>or</u> Missed), Preferences (program Ringtone, Contrast, Headset sidetone, and Backlight), Accessories (configure analog headset), and Extension Mobility (only if configured).
- 16 Messages Auto-dial access to voicemail.
- 17 Handset Phone Handset.

Copyright © 2003-2019, Maestri Consultants Inc. All rights reserved worldwide.

PLACING CALLS

To place a call:

- Lift the handset or Press the **Speaker** button or Press the Headset button or Press the New Call softkey or Press a line button
- Dial the number •

To place a second call on the same line:

- Press the Hold button ٠
- Press the New Call softkey
- Dial the number •

To call an extension number:

Dial the 5-digit extension number

To call the Receptionist:

• Dial 0

To call an external telephone number:

Dial 9 + 1 + telephone number ٠

To call Emergency Services:

Dial 911 or 9 + 911 •

To redial the last number called:

Press the Redial softkey ٠

To place a speed dial call:

- While on-hook, enter the speed dial code
- Press the SpeedDial softkey ٠

ANSWERING CALLS

To answer an incoming call:

• Lift the handset or Press the Speaker button or Press the **Headset** button or Press the **Answer** softkey or Press the flashing line button

To answer a second incoming call:

Press the flashing line button ٠

To answer a call on a shared line:

Press the flashing line button •

CALL PICK UP

To answer a ringing call on a call pickup group members phone:

- Go off-hook
- Press the **PickUp** softkey •

SINGLE NUMBER REACH (SNR)

To activate/deactivate SNR from your desk phone:

- Press the **Mobility** softkey
- Press the Select softkey to **Enable/Disable Mobile Connect**

To switch from your desk to your remote phone:

- Press the Mobility softkey
- Press the Select softkey to Send • call to Mobile Phone
- Answer your remote phone

To switch from your remote phone to your desk phone:

- Hang up the call on your remote phone
- Press the line button your desk phone

DECLINE

To immediately forward a ringing call to voicemail:

Press the **Decline** softkey •

ENDING CALLS

To end a call:

•

Replace the handset or Press the **Speaker** button or Press the **Headset** button or Press the End Call softkey

CALL HOLD

- To place a call on hold:
- Press the **Hold** button

To retrieve a held call:

Press the Hold button or Press the Resume softkey or Press the flashing line button

To toggle between two held calls on the same line:

Press the flashing line button •

To toggle between three or more

- held calls on the same line: Press the flashing line button •
- Navigate to the held call
- •
- Press the Resume softkey

To toggle between held calls on shared lines:

Press the flashing line button

CALL TRANSFER

To transfer a call:

- Press the Transfer button •
- Dial the extension number or **9** + **1** + telephone number*
- Option: Announce the caller •
- Press the **Transfer** button or Transfer softkey or hang up

If no answer or the line is busy:

- Press the Cancel softkey
- Press the **Resume** softkey or Press the flashing line button

To toggle between calls:

Press the Swap softkey •

To transfer two calls on the same line to one another:

- While connected to an active call. press the Transfer button
- Press the flashing line button
- Press the Yes softkey to confirm ٠ and complete the transfer

To transfer a call to a subscriber's voice mailbox:

- Press the **Transfer** button •
- Dial * + the voice mailbox number
- Press the **Transfer** button or Transfer softkey or hang up

CALL PARK

To put a call on hold at one phone and retrieve it at another:

Press the Park softkey Note: Displayed park number: 8000X • Hang up

To retrieve a parked call:

Dial the park number: **8000X**

CALL FORWARD ALL CALLS

To immediately forward all your incoming calls to another number:

- While on-hook, press the Fwd All softkey
- Dial the extension number or **9** + **1** + telephone number *or* Press the Messages button

To deactivate call forwarding:

Press the Fwd Off softkey

DO NOT DISTURB

To disable/re-enable the ringer for all incoming calls:

While on-hook, press the DND softkev

CONFERENCE CALLING

To place up to a 16-way conference call:

• While connected to an active call. press the **Conference** button Dial the next participant

Conference softkey

To add additional participants:

Repeat the above steps

To add an incoming caller to an

call, press the **Conference**

Press the flashing line button

and complete the conference

To view conference participants:

Press the **Details** softkey

Navigate to the participant to

Press the Remove softkey

CONFERENCE NOW

To dial into the 16-way conference

(Host's 5-digit extension) + #

If you are the host, enter your

PIN: , if not, press #

Enter the Attendee access code:

Dial: (978) 619-5660

Enter a meeting number:

(default: 1 2 3 4 5) + #

Note: If the host has not yet arrived,

you will be placed in the waiting room.

To remove a participant:

existing call or conference:

button

remove

•

•

service:

If not the host:

Option: Announce the conference

Press the **Conference** button or

While connected to the incoming

Press the **Yes** softkey to confirm